



BMW F800GS/F650GS Twin Instructions for Mounting F800GS Pack Rack and Micatech Top Case

Thank you for purchasing the Micatech BMW F800GS/F650GS Twin Pack Rack and Top Case. Please read through the installation instructions before you begin and call us if you have any questions at 1-888-464-6494.

Pack Rack Hardware:

4 – M8 x 55 Flat Head SS socket cap Screws

2 – Long aluminum spacers

2 – Short aluminum spacers

Overview

The Micatech Pack Rack is installed on top of the BMW rear deck, using the aluminum spacers provided.



Remove four screws from the BMW rear deck behind the seat that align with the four countersunk holes in the Micatech Pack Rack.

Install the two short spacers in the front holes and the two longer spacers in the rear holes.

Place the Pack Rack on top of the spacers and, using the flathead screws, install the rack. We recommend using blue Loctite to secure the screws.

Mount the Top Case

Mounting and removing the Micatech Top Case is very simple and requires no tools.

Locate the top case so the four holes in the bottom of the top case line up with the four female ¼- turns on the Pack Rack.

Insert male ¼-turns, pressing down, twist and lock. Note: When new, the ¼- turn fasteners may be hard to engage. If they are difficult to engage, try removing the thin rubber washer on the ¼-turns. If necessary, use a large flathead screwdriver, push down and twist clockwise to lock the ¼-turn fasteners.



Load up your gear and go!